



AF09GT

Program for static/dynamic axles weighing

STRUCTURE OF THE SET-UP - v8

ENGLISH



For 3590 series touch screen indicators

Table of contents

Introduction	4
Programming	4
Programming menu	5
Calibration	6
First Programming	16
AF09 functions	18
Generic functions	22
Shortcuts	24
Databases	30
Input texts	32
Serial ports	34
Printout / Ext. keyboard - Barcode reader	48
Digital outputs	50
Digital inputs - Remote control	54
Analog output	56
Backup and Restore	58
Diagnostic	60
List of functions	62

Dear Customer,
Thank you for purchasing a DINI ARGEO product.

This manual illustrates in detail the configuration set up structure of the AF09GT program, specific for weighing static or dynamic vehicles.
It especially describes all of the configuration parameters with the relative range of values which can be set and practical examples of programming, to help the technician while installing the indicator.



For any additional information or specific request, do not hesitate to contact your trusted retailer.

This document has been optimised for printing in A4 format.

Programming

How to access the menu:

1. Turn off the scale.
2. Turn the scale on and press the area at the top right of the display during switch-on.
3. Programming menu.



If the menu is password protected, it is only possible to access it by entering it. Alternatively, you can access partial set-up reserved for diagnostics.

*To view a customised logo upon switch-on, you must upload the image on SD.
If a switch-on message is set (**B 3**), no logo will be viewed.*

The letter has the sole purpose of indexing the parameters to make it easier to find them inside the manual, but it does not appear in the program.

A	Calibration	
B	First Programming	
C	AF09 functions	
D	Generic functions	
E	Shortcuts	
F	Databases	
G	Input texts	
H	Serial ports	
I	Printout	
J	Ext. keyboard - Barcode reader	
K	Digital outputs	
L	Digital inputs	
M	Remote control	
N	Analog output	
O	Backup & Restore	
P	Diagnostic	


KEY:

Parameter visible only in certain conditions.

Possible configurations of the parameter.

Parameter or menu subject to approval.

o (x) Indicates the default configuration.



KEY:



Parameter visible only in certain conditions.



Possible configurations of the parameter.



Parameter or menu subject to approval.



o (x) Indicates the default configuration.



A 1 1 Load cells type

Allows you to select analogue cells, digital cells, WWS wheel-weighing platforms or DGX conversion boards.

☒ Analog
 ☐ Digital DGX
 ☐ Digital RCD

☐ Digital CCI AD
 ☐ Digital RCD3D
 ☐ Digital C16i

☐ Digital WWS
 ☐ Digital RCPTD



DGX is a board which transforms up to four analogue cells into digital.
WWS is a digital wheel-weighing platform.

2 Number of cells (Scale 1)



Only visible if "Load cells type" = "Analog".

Allows you to select how many reading channels to use for the connection of each analogue platform.

1 - 4 (1).

3 Number of cells (Scale 1)



Only visible if "Load cells type" = "Digital".

For digital cells: for programming the number of digital cells used for each platform.

For DGX digital junction boards: for programming the total number of analogue cells connected to the DGX boards used.

1 - 16 (1) for digital cells.

1 - 24 (1) for analogue cells connected to DGX.

1 - 8 (1) for CCI AD digital cells.


4 Load cells distribution



Only visible if "Load cells type" = "DGX"


Indicates the total number of DGX boards and the division of the load cells for each DGX board.

Example 1




Platform with three DGX:
DGX1 - 4 analogue cells;
DGX2 - 2 analogue cells;
DGX3 - 4 analogue cells.

Example 2



Platform with three DGX:
DGX1 - 4 analogue cells;
DGX2 - 4 analogue cells;
DGX3 - 2 analogue cells.

Example 3



Platform with five DGX:
DGX1 - 2 analogue cells;
DGX2 - 2 analogue cells;
DGX3 - 2 analogue cells;
DGX4 - 2 analogue cells;
DGX5 - 2 analogue cells.

Number of DGX

Indicates the total number of DGX boards.

(In example 1 and 2, the total DGX is 3, in example 3 the total DGX is 5).

1 - 24 (1).

Number of cells (DGX1)

...

Number of cells (DGXn)

Indicates the number of analogue cells connected to the DGX board.






1 - 4 (1).



The number of cells for each DGX depends on the number of DGX boards.

A	Calibration	
B	First Programming	
C	AF09 functions	
D	Generic functions	
E	Shortcuts	
F	Databases	
G	Input texts	
H	Serial ports	
I	Printout	
J	Ext. keyboard - Barcode reader	
K	Digital outputs	
L	Digital inputs	
M	Remote control	
N	Analog output	
O	Backup & Restore	
P	Diagnostic	

1	Scale selection	
2	Scale 1	
3	Gravity value setting	
4	Zeroing percentage with ZERO key	
5	Automatic zeroing at start-up	

1	Load cells type	
2	Number of cells (Scale 1)	
3	Number of cells (Scale 1)	
4	Load cells distribution	
5	Serial number configuration	
6	WWS configuration	
7	Load cell polling time	

KEY:



Parameter visible only in certain conditions.



Possible configurations of the parameter.



Parameter or menu subject to approval.



o (x) Indicates the default configuration.

A 1 5 Serial number configuration



Only visible if "Load cells type" = "Digital". (parameter not available for CCI AD digital cells).

Allows you to transmit the relative identification number code to each cell/DGX board.

DGX1 / Cell 1

Enter the serial number of cell 1 / first DGX board.

DGXn / Cell n

Serial number cell *n* / DGX board *n*.


Address assignment

Transmission of data to cells/DGX boards.


A numerical index (from 1 to *n*) is assigned to each cell, according to the order of entry.

The physical layout of the load cells is not bound to the order of entry and therefore can be carried out according to your requirements:


Example of free numbering of digital cells




or



Example of free numbering of DGX boards



or



6 WWS configuration



Only visible if "Load cells type" = "Digital".

Specific menu for using digital WWS platforms.

WWS remote configuration

Allows you to access the technical set-up of the selected WWS.

Get WWS configuration

Allows the indicator to receive the weighing data from the WWS platforms connected.

7 Load cell polling time




Only visible if "Load cells type" = "Digital". (parameter not available for CCI AD digital cells).

Reading frequency of the digital load cells.

Increase the value if there are communication problems.

⚙️ 0 - 200 (0 for digital cells, 5 for WWS platforms).



KEY:



Parameter visible only in certain conditions.



Parameter or menu subject to approval.




Possible configurations of the parameter.



o (x) Indicates the default configuration.



A 2 1 1	Number of decimals			<input checked="" type="radio"/> 0 <input type="radio"/> 0.00 <input type="radio"/> 0.0 <input type="radio"/> 0.000
2	Unit of measure			<input type="radio"/> g <input type="radio"/> t <input checked="" type="radio"/> kg <input type="radio"/> lb
3	Number of ranges		Enables multi-range scales.	<input checked="" type="radio"/> 1 <input type="radio"/> 2 <input type="radio"/> 3
4	Multi range type			Only visible if "Number of ranges" > 1. <input checked="" type="radio"/> Multi range <input type="radio"/> Multi division
5	Division of Range 1		Division ("d" or "e") of the scale in case of single range, division of the first range in case of a multi-range scale.	<input type="radio"/> 1 <input type="radio"/> 10 <input type="radio"/> 100 <input type="radio"/> 2 <input checked="" type="radio"/> 20 <input type="radio"/> 50 <input type="radio"/> 200
6	Capacity / Range 1		Maximum range of the scale ("Max.") or first range for the multi-range scale.	<input checked="" type="radio"/> 0 - 999999 (60000).
7	Division of Range 2			Only visible if "Number of ranges" ≥ 2. Division of the second range for the multi-range scale.
8	Capacity / Range 2			Only visible if "Number of ranges" ≥ 2. Second range for the multi-range scale.
9	Division of Range 3			Only visible if "Number of ranges" = 3. Division of the third range for the multi-range scale.
10	Capacity / Range 3			Third range for the multi-range scale.
11	Filtering type		Adjustment of the weighing filter, modifies the reactivity of the scale. The "0" represents minor filtering incidence. Increasing the incidence give the weight more stability. We recommend weighing several times, changing the incidence until you obtain the best compromise between reactivity and stability.	<div> <p>With the approved tool, you can select only some of the filters listed.</p> </div> <div> <input checked="" type="radio"/> FLT 0 (CE-M) ... <input type="radio"/> FLT 3 (CE-M) <input type="radio"/> FLT.OFF <input type="radio"/> FLT.AV2 <input type="radio"/> H.R.0 (CE-M) <input type="radio"/> H.R.1 (CE-M) ... <input type="radio"/> H.R.7 <input type="radio"/> DYN.0 (CE-M) ... <input type="radio"/> DYN.3 <input type="radio"/> DOS.0 ... <input type="radio"/> DOS.3 <input type="radio"/> SLW.0 ... <input type="radio"/> SLW.3 <input type="radio"/> R.ADC D <input type="radio"/> R.ADC S <input checked="" type="radio"/> CUSTOM </div> <div> <p>Table and floor scales and piece counters.</p> <p> FLT 0 - FLT 1 - FLT 2 - FLT 3</p> <p>High precision scales.</p> <p> H.R. 0 - H.R. 1</p> <p>Suspended and oscillating load weighing.</p> <p> DYN 0 - DYN 1</p> <p>Metering, filling, level check and overloads</p> <p>Liquid weighing, weighbridges and weighing with vibrations.</p> <p>Filter for specific applications for use by the manufacturer.</p> </div>
12	CUSTOM filter configuration		For use by the manufacturer.	



13 Divisions for test of stability

Stability adjustment. The higher the value, the less sensitivity to variations, and therefore the weight is considered stable even in motion. This parameter acts on the instability symbol “~” and affects acquisition of weighs and printing.






⚙️ 0 - 99 (2). 0 = *always unstable*.


14 Zero tracking division

With the scale empty, it allows you to maintain the “zero weight” status over time, removing any filth, dust, processing residue within the time set in this step.

For example, setting “1/2 division” resets a weight equal to half division if stable for at least 1 second. Tracking acts at least within the manual zero reset limit, set in the step **A 4**.

⚙️

<input type="radio"/> No division	<input type="radio"/> 1/4 division	<input checked="" type="radio"/> 1/2 division
<input type="radio"/> 1 division 	<input type="radio"/> 2 divisions 	<input type="radio"/> 4 divisions 
<input type="radio"/> 8 divisions 	<input type="radio"/> 10 divisions 	



KEY:



Parameter visible only in certain conditions.



Possible configurations of the parameter.



Parameter or menu subject to approval.



o (x) Indicates the default configuration.



A 2 2 Equalisation



Only visible if "Number of cells (Scale 1)" > 1.

Wizard that enables you to digitally equalise the platform angles.

3 Calibration



Calibration wizard with the aid of sample masses (or known weights which can be freely set).

4 Zero calibration



Wizard to run after having completely calibrated the scale.

With the scale empty, it allows acquisition of the zero point, recalculating all the calibration points in proportion, maintaining the linearity obtained during the last calibration carried out. Useful to reset the structure weight or "dead tare" added at another time.

5 Calibration points

Allows you to quickly edit/correct/insert a calibration point.

Punkt	ADC	Last	ADC-mV
* 0	0	0	
1	1000000	60000	Ins
2	0	0	Del
3	0	0	Get
4	0	0	
5	0	0	
6	0	0	
7	0	0	
8	0	0	
Esc			

6 Theoretical calibration



Wizard for the temporary calibration of the weigh in a quick fashion, inserting in sequence the total range (sum of the ranges) and the average sensitivity of the cells ($\frac{\text{sum of the mV} / \text{V of each cell}}{\text{no. of cells}}$).

The theoretical calibration is useful for testing the system before the official calibration carried out with the sample masses.

7 Cells adjustment



Only visible if "Equalisation" is available.

For platforms with digital cells, it quickly modifies the equalisation coefficient of each individual cell. Useful when testing the system to quickly correct any errors in the angles.

WAAGE. 1		
Kanal	Eq. coeff.	Load %
* 1	1.000000	100.0
2	1.000000	-0.3
Esc - +		

3 Gravity value setting



If the tool calibrated in a certain area is shipped to a zone with different gravity acceleration, set the destination gravity in the step to automatically correct the weight.

9.75001 - 9.84999 (9.80390).

4 Zeroing percentage with ZERO key

Allows you to freely configure the resetting percentage of the key >0<, from 0 to 50% of F.S.

0 - 50% of F.S. (2%)

5 Automatic zeroing at start-up


Allows you to configure the auto reset function at switch-on:

☐ Disabled ☒ Enabled on the scale 1

2 Percentage of zeroing

Allows you to freely configure the resetting percentage at switch-on.

1 - 50% of F.S. (10%)



KEY:



Parameter visible only in certain conditions.



Parameter or menu subject to approval.



Possible configurations of the parameter.



o (x) Indicates the default configuration.



B 1 Language

☐ Italiano
 ☒ English
 ☐ Français
☐ Deutsch
 ☐ Español
 ☐ Português
☐ Polski

You may also add a custom language using the Dini Argeo "CustomLanguageTool" program
(Managed page codes: Latin 1, Greek, Cyrillic, Vietnamese).


2 Access password to setup


Allows you to protect the configuration set-up by means of a numerical 5-digit password, which you may freely set.

1 Enabling

☒ Disabled
 ☐ Enabled

2 Password

 Only visible if "Enabling" = "Enabled".

 0 - 65534



The password also blocks reception of the set-up by Dinitools (configuration program for pc).

3 Message to show at the startup

Allows you to customise the message displayed when the indicator switches on.

 Max. 32 characters



No logo is displayed when the switch-on message is inserted.

4 Touch screen calibration

Wizard to correctly calibrate the touch screen display, by pressing the displayed point.

5 Date and time setting

Configuration of the date and time of the tool. Function which can also be accessed from the weighing screen.

Datum/Zeit Einstellen

01 / 01 / 16

16 : 00

Abbruch OK


6 Date and time password


Allows you to protect the time and date configuration during weighing by means of a numerical 5-digit password, which you may freely set.


1 Enabling

☒ Disabled
 ☐ Enabled

2 Password

 Only visible if "Enabling" = "Enabled".

 0 - 65534



1

Minimum axle weight

2

Average weight samples

3

Cycles time interval (sec)

4

Beginning axles to skip

5

Ending axles to skip

6

Axle acquisition error enable

7

Speed limit

8

Platform width

9

Check minimum speed (1km/h)

10

WWS timeout

11

Send configuration to WWS

KEY:



Parameter visible only in certain conditions.



Possible configurations of the parameter.



Parameter or menu subject to approval.



o (x) Indicates the default configuration.

C 1	Axles weighing	<p>Allows you to choose the weighing acquisition mode.</p> <p> <input type="radio"/> Manual <input type="radio"/> Static <input checked="" type="radio"/> Dynamic </p>
2	Axles weighing configuration	<p>Setting of parameters for vehicle axle acquisition.</p>
1	Minimum axle weight	<p>Only visible if "Axles weighing" = "Dynamic" or "Static".</p> <p>Minimum weight value for each axle of the vehicle required to enable acquisition.</p> <p> <input type="text"/> 0 - MAX (750). </p>
2	Average weight samples	<p>Only visible if "Axles weighing" = "Dynamic" or "Static".</p> <p>Reading number when weighing each single axle.</p> <p>Set low values if the weight is unstable or high weighing ranges are requested.</p> <p>Set higher values if the weight is stable, thus improving weighing precision.</p> <p> <input type="text"/> 1 - 200 (30). </p>
3	Cycles time interval (sec)	<p>Only visible if "Axles weighing" = "Dynamic" or "Static".</p> <p>Number of seconds elapsed (with less weight of "Minimum axle weight") with which the weighing cycle ends automatically.</p> <p>Set a value equal to 0 to manage the weighing cycles from the input.</p> <p> <input type="text"/> 0 - 30 (10). </p>
4	Beginning axles to skip	<p>Only visible if "Axles weighing" = "Dynamic" or "Static".</p> <p>If automatic weighing has been configured, it is possible to set the number of axles not to accumulate at the beginning of the weighing cycle.</p> <p>It can be used to weigh the trailer only or to exclude an axle that is not required.</p> <p> <input type="text"/> 0 - 20 (0). </p>
5	Ending axles to skip	<p>Only visible if "Axles weighing" = "Dynamic" or "Static".</p> <p>If automatic weighing has been configured, it is possible to set the number of axles not to accumulate at the end of the weighing cycle.</p> <p>It can be used to exclude an axle that is not required.</p> <p> <input type="text"/> 0 - 20 (0). </p>
6	Axle acquisition error enable	<p>For use by the manufacturer.</p>
7	Speed limit	<p>Only visible if "Axles weighing" = "Dynamic".</p> <p>Maximum speed with which the vehicle can drive on the platform.</p> <p> <input type="text"/> 0 - 20 (5). </p>
8	Platform width	<p>Only visible if "Axles weighing" = "Dynamic".</p> <p>Allows you to calculate the correct speed of the vehicle.</p> <p>0 = Disabled.</p> <p> <input type="text"/> 0 - 255 (73). </p>
9	Check minimum speed (1km/h)	<p> <input checked="" type="radio"/> Disabled <input type="radio"/> Enabled </p>
10	WWS timeout	<p>Only visible if "Load cells type" = "Digital WWS".</p> <p>For use by the manufacturer.</p>
11	Send configuration to WWS	<p>Only visible if "Load cells type" = "Digital WWS".</p> <p>Send the configuration to the WWS.</p>
3	Double weigh enabling	<p>If enabled, it allows input/output weights for every vehicle.</p> <p>If disabled, it allows single weighing for every vehicle.</p> <p> <input type="radio"/> Disabled <input checked="" type="radio"/> Enabled </p>

A	Calibration	
B	First Programming	
C	AF09 functions	
D	Generic functions	1 Axles weighing
E	Shortcuts	2 Axles weighing configuration
F	Databases	3 Double weigh enabling
G	Input texts	4 Identification mode
H	Serial ports	5 ID code generation
I	Printout	6 Weigh when vehicle is selected
J	Ext. keyboard - Barcode reader	
K	Digital outputs	
L	Digital inputs	
M	Remote control	
N	Analog output	
O	Backup & Restore	
P	Diagnostic	

KEY:



Parameter visible only in certain conditions.



Possible configurations of the parameter.



Parameter or menu subject to approval.



o (x) Indicates the default configuration.

C 4 Identification mode

Allows you to select the type of identification of the weigh.


☒ By ID code
 ☐ By license plate

The "By ID code" is a progressive number from 1 to 999.

It is automatically associated to the first weigh stored and can be quickly recalled during acquisition of the second weigh, to calculate the difference of the net weight.


When the second weigh has been carried out, the ID is free and can be used once again.

By choosing the identification mode "By license plate", the first weigh is linked to the vehicle number plate.

The number plate can be entered manually at each weigh or else stored in the database.

5 ID code generation


The ID attributed to weighing can be progressive 1 to 999 (it starts from 1 again after reaching 999 weighs), or the first free ID (each ID is freed on completion of the second weigh).


☐ Using the first free ID code
 ☒ Always a next ID code

6 Weigh when vehicle is selected

Allow you to configure the tool for automatic vehicle weighing and identification of the weigh also in the absence of the user in charge of operations on the indicator.


☒ Disabled
 ☐ Enabled



1

Tare type

2

Semiautomatic tare

3

Add. tare before second weigh

4

Tare limitations for direct sale

KEY:



Parameter visible only in certain conditions.



Possible configurations of the parameter.



Parameter or menu subject to approval.



o (x) Indicates the default configuration.

D 1 Totalisation function mode

For use by the manufacturer.

2 Tare function

Tare functions configuration menu (if active on main screen).

1 Tare type

To avoid incorrect weighs, you may decide that the stored tare be cancelled automatically when the system is unloaded ("Unlocked").

If the tare is fixed and must remain active for several weighs, select "Locked"; this way the tare can only be cancelled manually.

Selecting "Disabled" inhibits every tare function.

⚙️ ☐ Unlocked ☒ Locked ☐ Disabled

2 Semiautomatic tare

⚙️ ☐ Disabled ☒ Enabled

3 Add. tare before second weigh

Enable the request to enter the additional tare on weighing output.

⚙️ ☒ Disabled ☐ Enabled

4 Tare limitations for direct sale

For use by the manufacturer.

3 Weighing mode reactivation

To avoid double acquisitions, you may decide whether the weighing functions, after a weigh, only reactivates after having unloaded the weighbridge ("Plate unloaded") or with unstable weight.

⚙️ ☒ Weight instability ☐ Complete scale unloading

4 Divisions for reactivation

👁️ Only visible if "Weighing reactivation mode" = "Weight instability".

If reactivation is set at "Weight instability", you may program the number of offset divisions from the recorded weigh to achieve reactivation.

⚙️ 1 - 99 (2).

5 Automatic calibration warning

Periodical system recalibration request warning by means of a displayed message.

The warning is not blocking.

1 Number of months

Number of months after which to view the message

⚙️ 0 - 99 (0).

2 Number of weighs

Number of weighs carried out after which to view the message

⚙️ 0 - 99999 (0).

6 Energy saving

Useful for battery operated systems, reducing consumption during idle periods.

1 Automatic switch-off

Automatic switch-off after 5 minutes not used, with scale empty

⚙️ ☒ Disabled ☐ Enabled

2 Screen timeout & Battery visual.

Switches off display back-lighting after 15 seconds (only when battery-operated).

⚙️ ☐ Disabled ☒ Enabled

7 Motherboard warming time

For special applications, a heating time of the motherboard can be set to avoid weight oscillations in the early moments when the tool is switched on.

⚙️ 0 - 60 (0).

8 Weight window zoom

Activates automatic display of the weight with large digits. This display is activated with weight stable and deactivated when the weight is unstable.

1 Enabling

⚙️ ☒ Disabled ☐ Enabled

2 Activation delay time

👁️ Only visible if "Weight window zoom" = "Enabled"

Large digit weight activation can be delayed by the time set in this parameter.

⚙️ 0 - 255 (5).

9 Buzzer sound of the instrument


Activates the audible warnings (buzzer) by pressing keys and with error conditions.

⚙️ ☐ Disabled ☒ Enabled

10 Electronic label

Disable/enable the electronic label

⚙️ ☒ Disabled ☐ Enabled



1

F1 - Preset tare

2

F2 - Preset tare

3

F3 - Preset tare

4

F4 - Preset tare

5

F5 - Preset tare

6

F6 - Preset tare

7

F7 - Preset tare

8

F8 - Preset tare

9

F9 - Preset tare

10

F10 - Preset tare

11

TARE / ESC - Tare

12

SCALE / HELP - Scale switching



13



ZERO / . - Zeroing

14

>> / OK - Screen switching

KEY:

-  Parameter visible only in certain conditions.
-  Possible configurations of the parameter.

-  Parameter or menu subject to approval.
-  o (x) Indicates the default configuration.

E 1 Keyboard customization


Allows you to configure the function of each key of the integrated keypad, if present.

The configuration menu of a key is displayed below (in following example "F1")



1 F1 - Preset tare	<div style="margin-bottom: 5px;"> <input type="radio"/> Disabled </div> <div style="margin-bottom: 5px;"> <input type="radio"/> User setup </div> <div style="margin-bottom: 5px;"> <input type="radio"/> User setup function by index </div> <div style="margin-bottom: 5px;"> <input checked="" type="radio"/> Single function (104) </div> <div style="margin-bottom: 5px;"> <input type="radio"/> Sequence 1 </div> <div style="margin-bottom: 5px; text-align: center;">...</div> <div style="margin-bottom: 5px;"> <input type="radio"/> Sequence 10 </div>	<p>Key disabled.</p> <p>Matches the "User setup": by pressing F1, in weighing, you access the menu which contains all the additional functions for the user.</p> <p>Matches the recall of the function by means of index: by pressing F1, in weighing, the user is requested to enter the identification number code of the function to carry out.</p> <p>Matches the direct recall of the function set: by pressing F1, in weighing, the function to be carried out is activated (for example reset, print, tare, set point programming etc.). When this mode has been selected, you directly access the "User setup" where all the available functions can be viewed (page 60).</p> <p>It is possible to match one of the 10 operational sequences. Each sequence can be programmed freely and allows you to queue up to 10 different functions, which will be recalled automatically, one after the other on pressing F1.</p> <p>For example the operator can be requested to enter 5 free texts in sequence, to perform the first weigh and to issue a receipt.</p>
---------------------------	---	---



The following is the default configuration of the other keys:

2 F2 - Preset tare	<input checked="" type="radio"/> Single function (104)	Preset tare.
3 F3 - Preset tare	<input checked="" type="radio"/> Single function (104)	Preset tare.
4 F4 - Preset tare	<input checked="" type="radio"/> Single function (104)	Preset tare.
5 F5 - Preset tare	<input checked="" type="radio"/> Single function (104)	Preset tare.
6 F6 - Preset tare	<input checked="" type="radio"/> Single function (104)	Preset tare.
7 F7 - Preset tare	<input checked="" type="radio"/> Single function (104)	Preset tare.
8 F8 - Preset tare	<input checked="" type="radio"/> Single function (104)	Preset tare.
9 F9 - Preset tare	<input checked="" type="radio"/> Single function (104)	Preset tare.
10 F10 - Preset tare	<input checked="" type="radio"/> Single function (104)	Preset tare.
11 TARE / ESC - Tare	<input checked="" type="radio"/> Single function (103)	Semi-automatic tare.
12 SCALE / HELP - Scale switching	<input checked="" type="radio"/> Single function (108)	Switching of active scale.
13 ZERO / . - Zeroing	<input checked="" type="radio"/> Single function (101)	Zero scale.
14 >> / OK - Screen switching	<input checked="" type="radio"/> Single function (301)	Switching of screen.




KEY:

-  Parameter visible only in certain conditions.
-  Possible configurations of the parameter.

-  Parameter or menu subject to approval.
-  o (x) Indicates the default configuration.

E 2 **Toolbar customization**

Allows you to configure the title and the function of the toolbar buttons.



The configuration menu of a toolbar key is displayed below (in following example “1. WEIGH”)

1 **Button 1 (1. WEIGH)****Title**

Allows you to edit the displayed title.

⚙ *Max. 8 characters (1.WEIGH).*

Button function

⚙ ☐ Disabled Key disabled.

☐ User setup

Matches the “User setup”: by pressing the key, in weighing, you access the menu which contains all the additional functions for the user.

☐ User setup function by index

Matches the recall of the function by means of index: by pressing the key, in weighing, the user is requested to enter the identification number code of the function to carry out (page 60).

☒ Single function (701)

Matches the direct recall of the function set: by pressing the key, in weighing, the function to be carried out is activated (for example reset, print, tare, set point programming etc.). When this mode has been selected, you directly access the “User setup” where all the available functions can be viewed (page 60).

☐ Sequence 1

...

☐ Sequence 10

It is possible to match one of the 10 operational sequences.

Each sequence can be programmed freely and allows you to queue up to 10 different functions, which will be recalled automatically, one after the other on pressing the key.

For example the operator can be requested to enter 5 free texts in sequence, to perform the first weigh and to issue a receipt.

The following is the default configuration of the other keys:

2 **Button 2 (2. WEIGH)****Title**

⚙ *2.WEIGH*

Button function

⚙ ☒ Single function (702)

3 **Button 3 (END)****Title**

⚙ *END*

Button function

⚙ ☒ Single function (720)

4 **Button 4 (>>)****Title**

⚙ *>>*


Button function

⚙ ☒ Single function (301)



BRUTTO		W1
10:00	kg	1
KUNDE		
LIEFERANT	ACHSEN (kg): N. 0	
MATERIAL	1.	
FAHRZEUG	2.	
TARA	3.	
SUMME	4.	
kg	5.	
→0←		→T←

Disabling all the keys increases the space available for customisations.
The message box drops to the bottom of the screen.



KEY:



Parameter visible only in certain conditions.



Possible configurations of the parameter.



Parameter or menu subject to approval.



o (x) Indicates the default configuration.



OPERATIONAL SEQUENCES

The program provides up to 10 operational sequences.

Each sequence can be programmed freely and allows you to queue up to 10 different functions, which will be recalled automatically, one after the other.

For example the operator can be requested to enter 5 free texts in sequence, to perform the first weigh and to issue a receipt.



Once you have selected the sequence you want to edit, the following screen appears:


	Präambel	Funktion
1	-1	Deaktiviert
2	-1	Deaktiviert
3	-1	Deaktiviert
4	-1	Deaktiviert
5	-1	Deaktiviert
6	-1	Deaktiviert
7	-1	Deaktiviert
8	-1	Deaktiviert
9	-1	Deaktiviert
10	-1	Deaktiviert

Selection of function by means of number code

HILFE OK

Help Online, displays the list of functions divided by type and relative number code. Otherwise all the functions are listed on page 60.

Preamble of the function.
Functions with preamble operate differently depending on the value entered.



1

Enabling database

2

Customer dtb customization

3

Material dtb customization

4

Vehicle dtb customization

5

Card dtb customization

6

Supplier dtb customization

7

Safety password

1

Enabling

2

Password

1

Enabling database

2

Customer dtb customization

3

Material dtb customization

4

Vehicle dtb customization

5

Card dtb customization

6

Supplier dtb customization

7

Safety password

1

Enabling

2

Password

1

Enabling database

2

Customer dtb customization

3

Material dtb customization

4

Vehicle dtb customization

5

Card dtb customization

6

Supplier dtb customization

7

Safety password

1

Enabling

2

Password

KEY:



Parameter visible only in certain conditions.



Possible configurations of the parameter.



Parameter or menu subject to approval.



o (x) Indicates the default configuration.



F 1 Enabling database

Allows you to select the records you want to use by simplifying archive programming.

☒ Customer dtb
 ☒ Material dtb
 ☒ Input dtb
☒ Vehicle dtb
 ☒ Card dtb
 ☒ Suppliers dtb

2 Customer dtb customization

Allows you to configure the required fields while filling out the customers database.

☒ Description 2
 ☒ Description 3

3 Material dtb customization

Allows you to configure the required fields while filling out the materials database.

☒ Description 2

4 Vehicle dtb customization

Allows you to configure the required fields while filling out the vehicles database.

☒ Description
 ☒ Tare

5 Card dtb customization

Allows you to configure the required fields while filling out the cards database.

☒ Linked customer
 ☒ Linked material
 ☒ Linked vehicle
☒ Linked text
 ☒ Linked supplier

6 Supplier dtb customization

Allows you to configure the required fields while filling out the suppliers database.

☒ Description 2
 ☒ Description 3

7 Safety password

Allows you to enable the access password to fill out the databases. The password is common for all databases.

1 Enabling

☒ Disabled
 ☐ Enabled

2 Password



Only visible if "Enabling" = "Enabled".

0 - 65534 (0).

A

Calibration

B

First Programming

C

AF09 functions

D

E

F

G

Input texts

H

I

J

K

L

M

N

O

P

1

(0001) Empty

...

49

(0049) Empty

KEY:



Parameter visible only in certain conditions.



Possible configurations of the parameter.



Parameter or menu subject to approval.



o (x) Indicates the default configuration.



INPUT TEXTS

The input texts are 49 memories filled out by the operator during weighing.
 They are used to enter information related to the weigh in progress (for example batch number, origin, operator code, a comment, traceability or visual quality control notes, etc.).

- Each input text consists of two parts:
- the header (16 characters) to identify and easily distinguish the input text (for example "LOT:");
 - the content (32 characters), filled out by the operator (for example "201601123455").

i The content of the input text can be programmed manually or by means of an external reader (barcode, chip card, badge, RFID).

The configuration menu of a free text is displayed below (in following example "testo di input 1")

G 1 (0000) Empty

Text 0001/0049	
Beschreibng	
Text	
Grenzwert	32
Eingabe obligator	Deaktiviert
Nur gült. Eingab	Deaktiviert
<div>←</div> <div>LÖSCHEN</div>	

Header of input text.

Content: filled out by the operator during weighing.
 When filling out the set-up field, it is shown to the operator as default text.

If the value received by the reader exceeds the set limit, it is saved in input text no.2

If enabled, once you have accessed free text to fill in, it is not possible to exit without having entered any data.

If enabled, the text can only be filled out if the text is not filled out.

The following is the default configuration of the following input texts:

- 2 (0002) Empty
- ...
- 49 (0049) Empty

i

Input texts can be viewed directly on the work screen, either under the form of buttons to access the content and as simple alphanumerical keys to read only.

BRUTTO		W1 #
10:00	kg	001
LOS		
LIEFERANT	ACHSEN (kg): N. 0	
FAHRER	1:	
FAHRZEUG	2:	
TARA	3:	
kg	4:	
STADT	5:	
kg	6:	
→0+	→T←	
ERSTW.	ZWEITW.	ENDE >>

A	Calibration
B	First Programming
C	AF09 functions
D	Generic functions
E	Shortcuts
F	Databases
G	Input texts
H	Serial ports
I	Printout
J	Ext. keyboard - Barcode reader
K	Digital outputs
L	Digital inputs
M	Remote control
N	Analog output
O	Backup & Restore
P	Diagnostic

1	Serial ports function mode
2	Printer port configuration
3	Pc port configuration
4	Auxiliary port configuration
5	Network configuration
6	Data transfer
7	Radio Frequency interface
8	Ethernet interface
9	Bluetooth interface

1	Baud rate
2	Parity type
3	Word length
4	Stop bit
5	CTS status
6	CTS Emulation Chars Number
7	CTS Emulation Interval
8	XON Character
9	XOFF Character
10	1st Reset command byte
11	2nd Reset command byte
12	3rd Reset command byte
13	4th Reset command byte
14	Second CTS status
15	Show the CTS error
16	Printer error timeout
17	Check paper status
18	Printer power supply
19	Protocol
20	Weight type To Alibi

KEY:



Parameter visible only in certain conditions.



Parameter or menu subject to approval.



Possible configurations of the parameter.



o (x) Indicates the default configuration.



H 1 Serial ports function mode

The three serial ports with which the tool is equipped can be used indiscriminately to communicate:

- in two-way mode with the PC ("PC" mode);
- in one-way mode with PC, printer, repeater and USBC memory ("Print." mode);
- in two-way mode with other auxiliary systems ("Aux" mode).

☒ 1=Pc 2= Stamp. 3=Aux
 ☐ 1=Pc 2= Aux 3=Stamp.
 ☐ 1=Stamp. 2= Pc 3=Aux
☐ 1=Stamp. 2= Aux 3=Pc
 ☐ 1=Aux 2= Pc 3=Stamp.
 ☐ 1=Aux 2= Stamp. 3=Pc

Serial ports | Printer port configuration

2 1 Baud rate

1200 - 2400 - 4800 - 9600 - 19200 - 38400 - 57600 - 115200 (9600).

2 Parity type

☒ None
 ☐ Odd
 ☐ Even

3 Word length

☐ 7 bit
 ☒ 8 bit

4 Stop bit

☒ 1 bit
 ☐ 2 bit

5 CTS status

Synchronism signal of printer/connected device:

Mod. "TPR" / "PR80" Dini Argeo: Low Mod. "LP542S" / "SMTPLUS" Dini Argeo: Low
 Mod. "LX300" / "TM295" Epson: Low Mod. "USBC" Dini Argeo: Low

☐ Disabled
 ☒ Low
 ☐ High
☐ Emulated
☐ XON/XOFF

6 CTS Emulation Chars Number

Only visible if "CTS status" = "Emulated". (For use by the manufacturer).

7 CTS Emulation Interval

Only visible if "CTS status" = "Emulated". (For use by the manufacturer).

8 XON Character

Only visible if "CTS status" = "XON/XOFF". (For use by the manufacturer).

9 XOFF Character

Only visible if "CTS status" = "XON/XOFF". (For use by the manufacturer).

10 1st Reset command byte

Only visible if "CTS status" = "XON/XOFF". (For use by the manufacturer).

11 2nd Reset command byte

Only visible if "CTS status" = "XON/XOFF". (For use by the manufacturer).

12 3rd Reset command byte

Only visible if "CTS status" = "XON/XOFF". (For use by the manufacturer).

13 4th Reset command byte

Only visible if "CTS status" = "XON/XOFF". (For use by the manufacturer).

14 Second CTS status

Synchronism signal of second printer / connected device (terminal 19 of motherboard).

☒ Disabled
 ☐ Enabled

15 Show the CTS error

Only visible if "Second CTS status" = "Enabled" or if "CTS status" ≠ "Disabled".

Useful when printing is fundamental and the weight must not be acquired if the printer is not ready.

☐ Disabled
 ☒ Enabled

16 Printer error timeout

Only visible if "Second CTS status" = "Enabled" or if "CTS status" ≠ "Disabled". (For use by the manufacturer).

17 Check paper status

For use by the manufacturer.

18 Printer power supply

Select the "External" power supply mode in order to keep the printer ON when using the indicator.

Select "External auto switch off" for printers in energy saving mode.

Select "Internal" power supply mode in order to switch on the printer when issuing the receipt only.

☐ External
 ☐ External auto switch off
 ☒ Internal

19 Protocol

☒ Standard
 For printer.

☐ Repeater 6 digits
 For repeater mod. Dini Argeo

☐ For alibi memory
 Each weigh will be stored in the alibi memory (to be able to print the alibi value at each weigh, the printed format must be modified with the adequate macro).


☐ Continuous
 Continuous transmission of standard weight string.

20 Weight type To Alibi

Only visible if "Protocol" = "For alibi memory"

You may select which weight to save in the alibi memory, in addition to the tare value:

☒ Gross weight
☐ Net weight



KEY:



Parameter visible only in certain conditions.



Parameter or menu subject to approval.



Possible configurations of the parameter.



o (x) Indicates the default configuration.



- H 3 1 **Baud rate**
- 2 **Parity type**
- 3 **Word length**
- 4 **Stop bit**
- 5 **CTS status**

⚙️ 1200 - 2400 - 4800 - 9600 - 19200 - 38400 - 57600 - 115200 (9600).

⚙️ ☒ None ☐ Odd ☐ Even

⚙️ ☐ 7 bit ☒ 8 bit

⚙️ ☒ 1 bit ☐ 2 bit

Synchronism signal of printer/connected device:

Mod. "TPR" / "PR80" Dini Argeo: Low Mod. "LP542S" / "SMTPLUS" Dini Argeo: Low

Mod. "LX300" / "TM295" Epson: Low Mod. "USBC" Dini Argeo: Low

⚙️ ☒ Disabled ☐ Low ☐ High
☐ Emulated

Set "Disabled" to communicate with the PC.



In the PC port, the CTS signal is managed by the RX pin.

6 **CTS Emulation Chars Number**

Only visible if "CTS status" = "Emulated". (For use by the manufacturer).


7 **CTS Emulation Interval**

Only visible if "CTS status" = "Emulated". (For use by the manufacturer).

8 **Protocol**

Setting the communication protocol

- ⚙️ ☒ Standard To transmit the standard DINI ARGEO string.
- ☐ Extended To transmit the extended string.
- ☐ Repeater 6 Digits For repeater mod. DINI ARGEO.
- ☐ Repeater of Lcd display -
- ☐ Monodirectional -
- ☐ For alibi memory Each weigh is stored in the alibi memory and transmitted to the PC.
- ☐ SMA -
- ☐ Modbus -
- ☐ Profibus -
- ☐ B Type -
- ☐ Repeater B -
- ☐ B3 Type -
- ☐ B4 Type -
- ☐ Network Activates the "network between tools" mode.



KEY:



Parameter visible only in certain conditions.



Parameter or menu subject to approval.



Possible configurations of the parameter.




o (x) Indicates the default configuration.




9 Communication mode

Selection of the communication mode:


-  ☒ On demand The tool responds or runs operations according to the command received.
- ☐ Continuous Continuous transmission of standard weight string.
- ☐ Stability The tool transmits the standard weight string whenever the weight is stabilised.
- ☐ RS485 mode Communication with RS485 identification number code.
Commands without code or with a different code will be ignored.
- ☐ Get axle Transmission of the string to acquisition of each axle:
"Axle; Axle number; Weight; Unit of measure".
E.g. "Axle 1 3000 kg", "Axle 2 3000 kg".
- ☐ Total weight Transmission of the string to closing an input/output weigh:
"Axles; Total number of axles; Weight; Unit of measure".
E.g. "Axles 3 16000 kg".
- ☐ Input Transmission of the string to closing an input weigh:
"IN; Number of weighs; Total weight at the entrance; Unit of measure".
E.g. "IN 3 36000 kg".
- ☐ Output Transmission of the string to closing an output weigh:
"OUT; Number of weighs; Total weight output; Unit of measure".
E.g. "OUT 3 35480 kg".
- ☐ Upon end cycle String sent at the end of the first/second weigh cycle.

10 485 address

If the communication mode is "RS485", set the identification code of the tool.

 0 - 99 (0).

To dialogue with the scale you must add the identification code of the tool at the start of each command.



KEY:



Parameter visible only in certain conditions.



Parameter or menu subject to approval.



Possible configurations of the parameter.



o (x) Indicates the default configuration.



H 4 1

Baud rate

1200 - 2400 - 4800 - 9600 - 19200 - 38400 - 57600 - 115200 (9600).

2

Parity type

None Odd Even

3

Word length

7 bit 8 bit

4

Stop bit

1 bit 2 bit

5

CTS status

Synchronism signal of printer/connected device:

Mod. "TPR" / "PR80" Dini Argeo: Low Mod. "LP542S" / "SMTPLUS" Dini Argeo: Low
Mod. "LX300" / "TM295" Epson: Low Mod. "USBC" Dini Argeo: Low

Disabled Low High
Emulated

Set "disabled" to communicate with the PC.

6

CTS Emulation Chars Number

Only visible if "CTS status" = "Emulated". (For use by the manufacturer).

7

CTS Emulation Interval

Only visible if "CTS status" = "Emulated". (For use by the manufacturer).

8

Protocol

Disabled -

Standard To transmit the standard DINI ARGEO string.

Repeater 6 Digits For repeater mod. DINI ARGEO.

Repeater DC Configures up to 3 weight repeaters, each of which displays different information.

Network Activates the "network between tools" mode.

9

Send data for Repeater DC


Only visible if "Protocol" = "Repeater DC"

Configuration of "Ripetitore DC" protocol in order to connect several repeaters in RS485 network and to simultaneously view different weights:

Scale 1 (Address 01)

Disabled Only if active Always

i For platforms with digital cells, the network of repeaters can be connected directly to the RS485 network of the cells.



KEY:



Parameter visible only in certain conditions.



Parameter or menu subject to approval.



Possible configurations of the parameter.



o (x) Indicates the default configuration.



H 5 Network configuration




Only visible if "Protocol" = "Network" in "Pc port configuration" or "Auxiliary port configuration".

Configuration menu of network between tools.

The network between tools allows you to share the databases and weighs carried out in real time, implementing systems with several indicators.

Example



1 Node group

A group of nodes is a set of indicators, linked via Ethernet, which share the weighs database and the other databases. There can be several node groups linked to the same corporate Ethernet circuit.


⚙ 1 - 8 (1)

2 Node ID

Identifies the tool in its group of origin.

⚙ 1 - 32 (1)

Example



3 IP Mode

⚙ ☒ Static IP address ☐ Dynamic IP address

4 IP Address



Only visible if "IP Mode" = "Static IP address".
Allows you to configure IP address

⚙ 0 - 255 (0. 0. 0. 0).

5 Subnet mask



Only visible if "IP Mode" = "Static IP address".
Allows you to configure the subnet mask.

⚙ 0 - 255 (255. 255. 255. 0).

6 Automatic db alignment

Each record in the database and each new weigh are shared in real time by all tools online belonging to the same group.

⚙ ☐ Disabled ☒ Enabled


7 Network name

Allows you to program the name of the Ethernet module for quick identification in the corporate network (e.g.: "Indicator 1", "Office indicator").

⚙ Max. 15 characters.

8 Send network configuration

Send the configuration to the Ethernet module.



1

Data transfer device

2

Data transfer separator

KEY:



Parameter visible only in certain conditions.



Possible configurations of the parameter.



Parameter or menu subject to approval.



o (x) Indicates the default configuration.


H 6 Data transfer

Data transfer configuration.


1 Data transfer device

Set the communication port(s) on which to transmit data.


☐ Pc port
 ☐ Auxiliary port
 ☐ USB
 ☐ SD
 ☐ Internal Ethernet TCP
 ☐ Internal Ethernet UDP


 Visible only in models with 8" display.

2 Data transfer separator

 Visible only if at least one port has been selected in "Data Transfer Device".

Allows you to configure the separator character (ASCII code) between print blocks.

 0 - 255 (59 ";")



KEY:



Parameter visible only in certain conditions.



Parameter or menu subject to approval.



Possible configurations of the parameter.



o (x) Indicates the default configuration.



H 7 Radio Frequency interface

Configuration of radiofrequency module.

1 Communication port

Set the communication port which the radiofrequency module is connected to.

☒ Disabled
 ☐ Pc port
 ☐ Printer port
 ☐ Auxiliary port

2 Channel

Allows you to configure the radio channel used by the radiofrequency module to communicate. Once the selection of the channel has been confirmed, the tool automatically sends the new configuration to the radio module.

Refer to the manual of the radio module for the choice of the radio channel (QSG_RF2G4).

H 8 Ethernet interface

Allows you to configure the Ethernet module to communicate with the corporate computer system.

1 Interface type

☒ External (ETHD)
 ☐ Internal TCP
 ☐ Internal UDP

Only visible on 8 inch models. Only visible on 8" models.

2 Communication port

☒ Disabled
 ☐ PC port
 ☐ Printer port
 ☐ Device name

3 IP mode

☒ Static IP address
 ☐ Dynamic IP address

4 IP address

Configuring the "Static IP" mode allows you to configure the IP address.

0. 0. 0. 0

5 Subnet mask

Configuring the "Static IP" mode allows you to configure the subnet mask.

255. 255. 255. 0

6 Send configuration

Allows you to send the configuration to the Ethernet module.

H 9 Bluetooth interface

Configuration of bluetooth module.

1 Communication port

Set the communication port which the bluetooth module is connected to.

☒ Disabled
 ☐ PC port
 ☐ Printer port
 ☐ Porta ausiliaria

2 Device name

Enables you to configure the name that identifies the device (i.e. the indicator).

The default name is recommended: BTDA_XXX, editable.

Max. 20 characters.

3 Role

Enables you to configure the operating mode.

☒ Slave
 ☐ Master

By selecting "Slave", the indicator waits for a master device to request connection, for example to a PC.

By selecting "Master", the indicator requests connection to a master device, for example a scanner, printer, or other Slave indicator, etc.

4 Associated device

Only visible if "Role = Master".

The indicator activates a search for available devices and displays them on the screen. Select the device to associate.

5 Send configuration

Allows you to send the configuration to the bluetooth module.



The parameters from H 8 3 to H 8 6 are only visible if "Communication port" (H 8 2) ≠ "Disabled"


The parameters from H 9 2 to H 9 5 are only visible if "Communication port" (H 9 1) ≠ "Disabled"


A	Calibration	
B	First Programming	
C	AF09 functions	
D	Generic functions	
E	Shortcuts	
F	Databases	
G	Input texts	
H	Serial ports	
I	Printout	
J	Ext. keyboard - Barcode reader	
K	Digital outputs	
L	Digital inputs	
M	Remote control	
N	Analog output	
O	Backup & Restore	
P	Diagnostic	

1 Keyboard port use

2 External pc keyboard type

3 Barcode reader serial port

4 Input text automatic compilation 

5 Barcode reader length threshold 

6 Barcode reader use

KEY:



Parameter visible only in certain conditions.



Possible configurations of the parameter.



Parameter or menu subject to approval.



o (x) Indicates the default configuration.

I 1 Printout headings

Filling out the "Line", these appear in the print header.

1 Line 0

⚙ Max. 24 characters.

2 Line 1

⚙ Max. 24 characters.

3 Line 2

⚙ Max. 24 characters.

Ext. keyboard - Barcode reader

J 1 Keyboard port use

Allows you to define whether the keyboard emulation inlet, on the display board, is connected to an external PC keyboard (PS2) or to a card reader.

⚙ ☒ Connected to a pc keyboard ☐ Connected to a barcode reader

2 External pc keyboard type

⚙ ☐ Italiano ☐ Français ☐ Deutsch
☒ English

Italiano / English = QWERTY

Français = AZERTY

Deutsch = QWERTZ


3 Barcode reader serial port

Allows you identify the port which the serial barcode / Badge / Tag / RFID reader is connected to.

If "Not connected" is selected, connect the external reader/keyboard to the connector on the display board.

⚙ ☒ Not connected ☐ Printer port ☐ Auxiliary port

4 Input text automatic compilation

 Only visible if "Keyboard port use" = "Connected to a barcode reader" or "Barcode reader serial port" ≠ "Not connected".

Enables or disables autofill of free text 0.

⚙ ☒ Disabled ☐ Enabled

5 Barcode reader length threshold

 Only visible if "Input text automatic compilation" = "Enabled".

For use by the manufacturer.


6 Barcode reader use

Allows you to set the operating mode of the barcode / Badge / Tag / RFID reader.

⚙ ☐ Search card Quick selection of records and execution of weigh. Use the description of the card, even partial, as a search criteria.

☒ Search card for whole word only Quick selection of records and execution of weigh. Use the complete description of the card as a search criteria.

☐ Search ID code Execution of second weigh by quickly recalling the ID of the first weigh. Use the weigh ID as a search criteria.



KEY:



Parameter visible only in certain conditions.



Possible configurations of the parameter.



Parameter or menu subject to approval.



o (x) Indicates the default configuration.

The tool is set up for 4 digital outputs on the motherboard, which can be expanded to 16 with the optional expansion board.

K 1 Function mode

Allows you to activate only one relay at a time ("Exclusive" mode); useful for managing multi-colour traffic lights.

⚙️ ☒ Normal ☐ Exclusive

The configuration menu of a digital output is displayed below (in following example "Output 1").

2 Output 1

1 Function

⚙️ ☒ Disabled -

☐ Gross weight Switching of the relay on the set point (gross weight).

☐ Net weight Switching of the relay on the set point (net weight).

☐ Gross weight = 0 The relay switches when the gross weight is equal to 0.

☐ Net weight = 0 The relay switches when the net weight is equal to 0.

☐ Instability Switching of the relay at instability of the weight.

☐ Totalisation done Activated upon execution of the single weigh and of the double weigh.

☐ Setpoint on the partial total Function can be used when the first weigh is greater than the second.

☐ Setpoint on the general total Function can be used when the first weigh is greater than the second.

☐ Setpoint on the grand total Function can be used when the first weigh is greater than the second.

☐ Negative net weigh Set point that can be set on the net negative weight.

☐ Double or single weigh Activation of the relay after first, second or single weigh acquired.

☐ Weigh acquisition Activation of relay at each weigh carried out.

☐ Traffic light Function which regulates passage of the vehicle on the weighing system (can be activated by means of 2 outputs).

☐ Axle acquisition The set point is active when the weight of the axle exceed the "Minimum axle weight" **C 2 1** and remains active until its acquisition.

☐ Axle acquisition error If the indicator triggers an "Axle acquisition error", the relay is activated intermittently until the end of the acquisition cycle.

☐ Axles total setpoint It is enabled upon reaching the total axle weight in a single cycle (setting the set point). It remains active until a new cycle is started.

☐ Generic axle out of tolerance Activation of relay when an axle is out of tolerance. The relay returns to the initial status at passage to 0 (setting the set point).

☐ Axle 1 out of tolerance Activation of relay when the axle is out of tolerance. The relay returns to the initial status at passage to 0 (setting the set point).

...

☐ Axle 10 out of tolerance

☐ Traffic L. yellow cycle Activation of relay when weigh carried out. Tells the user to unload the weighbridge. Function can be activated coupled to "Traffic light" function.

☐ In axles weighing cycle Activation of relay on opening a weighing cycle. It remains active until its end.

2 Contact status


Normally open/normally closed

⚙️ ☒ Normally opened (NO) ☐ Normally closed (NC)

3 Condition for activation

The output can be activated immediately when the set threshold is reached ("Direct" mode) or waits for stability.

⚙️ ☒ Direct ☐ At the weight stability



1

Function

2

Contact status

3

Condition for activation

4

Hysteresys

KEY:



Parameter visible only in certain conditions.



Possible configurations of the parameter.



Parameter or menu subject to approval.




o (x) Indicates the default configuration.


4 Hysteresys

Enables double threshold operation (activation weight threshold \neq from output deactivation weight threshold)

 ☒ Disabled

☐ Enabled





Single threshold: the relay switches when the set threshold is exceeded. It goes back to the initial condition when the weight value has dropped below the threshold.

Double threshold: the relay switches when the set threshold is exceeded. It goes back to the initial condition when the weight value has dropped below the hysteresis threshold.


The following is the default configuration of the following outputs:


- Output 2 ... Output 16
- Function


Contact status


Condition for activation


Hysteresys

 ☒ Disabled


 ☒ Normally opened (NO)

 ☒ Direct

 ☒ Disabled



The parameter of output 2 and output 3 is set to "Function" = "Net weight".



KEY:



Parameter visible only in certain conditions.



Possible configurations of the parameter.



Parameter or menu subject to approval.



o (x) Indicates the default configuration.

The tool is set up for 2 digital inputs on the motherboard, which can be expanded to 8 with the optional expansion board.

L 1 **Input 1 (motherboard)**

~

8 **Input 8 (expansion board)**

Allows you to associate the desired function to input 1.

⚙️

☒ Disabled

☐ Key

☐ User setup

☐ User setup function by index

☐ Single function

☐ Sequence 1

☐ Sequence 2

...

☐ Sequence 10

☐ Lock/Unlock keyboard

☐ Indicator turning off

☐ Show "-----" on the display

☐ Disable all the digital outputs

☐ Simulation of key long pression

☐ Connection to a level controller

☐ OUT1 and OUT2 for dosage

☐ Weighing cycle enable

☐ First weigh consensus

☐ Second weigh consensus

-

Simulates short pressing of a key (for indicators with a keyboard).

ON with user set-up.

Enables the request of the desired function on the display.

Allows you to associate a specific function of the user menu to the input.

Allows you to associate one of the 10 sequences available.

If active, it locks the keyboard; if disabled, it unlocks it.

If active, it switches off the indicator; restarting is only possible from the keyboard.

If active, it inhibits the weight.

If active, it disables all relay outputs.

If active, pressing any key on the keyboard will be considered as "long", thus enabling the second function.

If active, it inhibits the weight. Useful to manage the electronic spirit level.

If active, it enables consent for simple dosing.

If enabled, it allows vehicle weighing. It can be enabled by means of a pulse.

If disabled, it prevents input weighing.

If disabled, it prevents output weighing.

Remote control

M 1 **Type**

Allows you to configure the type and operation of the remote control.

⚙️

☒ Disabled

☐ Radio 6 keys

☐ Radio 6 keys in broadcast mode

☐ Radio in tag emulation

The use this function, the remote control must be associated to the indicator (max 3 remote controls).

Supports up to 6 remote controls for each indicator without needing to associate them.

i By selecting the types of remote control "Radio 6 keys" and "Radio 6 keys in broadcast mode", the desired function must be associated to each key (6) choosing between: Disabled, Key simulation, User set-up, User set-up function from index, Single function, Sequence 1... 10, Lock/Unlock keyboard, Indicator switch-off, View "-----" on display, Disable all outputs, Long press simulation, Connected to level controller.

Only visible if "Tipo" = "Radio 6 keys" or "Radio 6 keys in broadcast mode".

By selecting the types of remote control "Radio 6 keys" and "Radio 6 keys in broadcast mode", the desired function must be associated to each of the 6 keys.

2 **Key 1**

3 **Key 2**

4 **Key 3**

5 **Key 4**

6 **Key 5**

7 **Key 6**

⚙️

☒ Tare


☒ Zeroing

☒ First weigh

☒ Second weigh

☒ ON-OFF / CLEAR

☒ Close weighing cycle



KEY:



Parameter visible only in certain conditions.



Possible configurations of the parameter.



Parameter or menu subject to approval.



o (x) Indicates the default configuration.

The tool, equipped with optional expansion board, is set up for installation of an analogue output proportional to the weight of the displayed scale (0 ... 5V, 0 ... 10V, 0 ... 20mA, 4 ... 20mA).

N

1

General settings

1

Communication port

⚙

☒ Disabled

☐ Printer port

☐ Auxiliary port

2

Expansion board slot

⚙

☒ Slot 1

☐ Slot 2

3

Function

⚙

☒ Proportional to the gross weight

☐ Proportional to the net weight

2

Scale 1

1

Value related to full capacity

⚙

0 - 65535 (63250)

2

Value related to unloaded scale

⚙


0 - 65535 (1300)


3

Value related to underload

⚙

0 - 65535 (1300)





KEY:

Parameter visible only in certain conditions.

Possible configurations of the parameter.



Parameter or menu subject to approval.



o (x) Indicates the default configuration.

0 1 Backup of the configuration

Allows you to store the current configuration and to protect it with a password, in order to quickly restore operation of the indicator in case of malfunctioning due to incorrect tampering with the set-up.

2 Clearing of ACW counters

Allows you to reset the counters managing the automatic recalibration warning (**D 4**).

3 Restore keys

Allows you to restore the default features of the keyboard (if present), of the function sequences and of the touch buttons in the work screens.

4 Databases initialization

Allows you to delete the contents of the selected archives, restoring them back to their default settings.

⚙

<input checked="" type="checkbox"/> Customer dtb	<input checked="" type="checkbox"/> Material dtb
<input checked="" type="checkbox"/> Input texts	<input checked="" type="checkbox"/> Vehicle dtb
<input checked="" type="checkbox"/> Progressives dtb	<input checked="" type="checkbox"/> Card dtb
<input checked="" type="checkbox"/> Suppliers dtb	<input checked="" type="checkbox"/> Weighs dtb

5 Restore printouts

Allows you to restore the default condition of all printing formats and the work screens of the display.

6 Alibi memory initialization

Enables you to delete the content of the alibi memory.

7 Cancellation of the buffered RAM

Allows you to reset all the buffered RAM memory (except the serial number and digital cells), resetting the default status of the database (and relative parameters), of totals, progressives, keys and printouts.

8 Restore functioning settings

Allows you to restore the features of the indicator to the default condition.

9 Restore all settings

Allows you to cancel all the settings (calibration, key configuration, databases, prints, alibi memory, buffered RAM, features) by restoring the default condition.

- A Calibration
- B First Programming
- C AF09 functions
- D Generic functions
- E Shortcuts
- F Databases
- G Input texts
- H Serial ports
- I Printout
- J Ext. keyboard - Barcode reader
- K Digital outputs
- L Digital inputs
- M Remote control
- N Analog output
- O Backup & Restore
- P Diagnostic

- 1 Indicator information
- 2 Weight test
- 3 Display test
- 4 Keyboard test
- 5 Voltage levels
- 6 Serial ports test
- 7 CTS test
- 8 Printout test
- 9 Outputs and Inputs test
- 10 Analog output test
- 11 Event log viewer

KEY:



Parameter visible only in certain conditions.



Possible configurations of the parameter.



Parameter or menu subject to approval.



o (x) Indicates the default configuration.



P 1 Indicator information

Summarised screen of the main metrological information.

EGT-AFxx-DE	
Instrument Typ	01
Messtechn. Software-Version	01
Software-Version	01.00.00
Hardware-Version	08
Loader-Version	2.08
Serien-Nummer	12345678
Display-Version	01.00.00
Netzwerk Version	
UNGEEICHT NUTZUNG	
g= 9.80390m/s ²	
Esc	

Prefix: identifies the tool model
Version: identifies the legal software

2 Weight test

Displays the current weight of the scale, even in error conditions (underload, overload, etc.).

3 Display test

Display of basic colours in sequence (White / Black and RGB)

4 Keyboard test

Allows you to verify correct operation of the touch screen and of the built-in keyboard (if present).

5 Voltage levels

Displays the voltage value at the input of the power supply and battery (if present).

6 Serial ports test

For use by the manufacturer.

7 CTS test

Test of the status of the control signal from the printer.

8 Printout test

Allows you to send the printer the selected printing format (from "1" to "30" or else "0" to send all formats).

9 Outputs and Inputs test

Allows you to verify the status of the digital inputs and testing of the relay outputs/built-in traffic light.
 By clicking the desired output you activate/deactivate the connected device.
 Click "R", "Y" or "G" to test the built-in traffic light (if present).


10 Analog output test

Allows you to test the analogue output: enter a digital value for real time updating of the analogue output.

11 Event log viewer

Views the list of the last ten events of the selected category:

Ereignis - Anzeige	
<input checked="" type="radio"/>	MESSTECHN. EREIGNISSE
<input type="radio"/>	AKKU EREIGNISSE
<input type="radio"/>	ÜBERLAST EREIGNISSE
<input type="radio"/>	SETUP-EREIGNISSE
<input type="radio"/>	FW UPDATE EREIGNISSE
<input type="radio"/>	NETZ-EREIGN.
Abbruch	
OK	




List of functions

Scale functions		Preamble	Description
101	Zeroing	-	Manual reset of weight within +/- 2% of F.S.
103	Tare	-	Acquisition of tare weight by pressing the dedicated key.
104	Preset tare	from 0 to Max	Manual tare value entry function.
105	Lock/Unlock tare	-	Exchanges the "Lock tare" feature with "Unlock tare".
106	Weight switching	-	If there is a tare, it exchanges the display between "Net weight" and "Gross weight".
107	Weight in high resolution	-	Useful for metrological tests, allows you to view the weight with a sensitivity ten times higher.

Printout		Preamble	Description																																						
201	Printer turning on	-	If the tool is equipped with an integrated printer, this function allows you to switch it on manually for configuration or to change the roll.																																						
202	Simple printout	-	Allows you to print the weight on the scale without increasing the totals.																																						
203	Last printout copy	-	Allows you to issue an exact copy of the last print carried out, freezing the weights and all the weigh data (databases, texts, etc.).																																						
204	Change the printout format	-1	Accesses the association table of the printing formats.																																						
			<table><tr><th>Print function</th><th>Index (xx)</th></tr><tr><td>Simple print</td><td>001</td></tr><tr><td>Partial total</td><td>002</td></tr><tr><td>General total</td><td>003</td></tr><tr><td>Grand total</td><td>004</td></tr><tr><td>Single weighing</td><td>005</td></tr><tr><td>First weigh</td><td>006</td></tr><tr><td>Second weigh</td><td>007</td></tr><tr><td>Customer total</td><td>008</td></tr><tr><td>Material total</td><td>009</td></tr><tr><td>Vehicle total</td><td>010</td></tr><tr><td>Print at start-up</td><td>011</td></tr><tr><td>First axle</td><td>012</td></tr><tr><td>Subsequent axles</td><td>013</td></tr><tr><td>End weighing cycle</td><td>014</td></tr><tr><td>Calculator result</td><td>015</td></tr><tr><td>Cycle error</td><td>016</td></tr><tr><td>Supplier total</td><td>017</td></tr><tr><td>Reprint format</td><td>018</td></tr></table>	Print function	Index (xx)	Simple print	001	Partial total	002	General total	003	Grand total	004	Single weighing	005	First weigh	006	Second weigh	007	Customer total	008	Material total	009	Vehicle total	010	Print at start-up	011	First axle	012	Subsequent axles	013	End weighing cycle	014	Calculator result	015	Cycle error	016	Supplier total	017	Reprint format	018
			Print function	Index (xx)																																					
			Simple print	001																																					
Partial total	002																																								
General total	003																																								
Grand total	004																																								
Single weighing	005																																								
First weigh	006																																								
Second weigh	007																																								
Customer total	008																																								
Material total	009																																								
Vehicle total	010																																								
Print at start-up	011																																								
First axle	012																																								
Subsequent axles	013																																								
End weighing cycle	014																																								
Calculator result	015																																								
Cycle error	016																																								
Supplier total	017																																								
Reprint format	018																																								
Single preamble from 1 to 18	Allows you to assign the desired printing format to the function indicated in the preamble.																																								
Double preamble in format xxyy xx: from 1 to 18 yy: from 1 to 30	Allows you to assign the desired printing format (yy) to the printing function (xx).																																								
205	Printout format sending	-1	Accesses the printing formats table.																																						
		from 1 to 30	Allows you to send the printer the specified printing format.																																						
206	Ticket copies number	from 1 to 10	Allows you to set the number of copies issued for each print carried out.																																						
207	Printer error management	-	For use by the manufacturer.																																						

Generic functions		Preamble	Description
301	Screen switching	from 1 to 3	Allows you to exchange the operating screen among the three available.
302	Lock keyboard	-	Allows you to lock the indicator keyboard to prevent unintentionally pressing the keys. The keyboard is unlocked by means of the guided key combination.
303	Date and time setting	-	Allows you to adjust date and time.
304	Calculator	-	Recalls the calculator function.
305	Outputs setpoint setting	-1	Accesses the set points summary table.
		from 1 to 16	Recalls the menu where the relays activation/deactivation value is set.
306	Alibi memory reading	-	Allows you to check each weigh saved in the alibi memory.
307	Enable/disable zoom	-	Activates/deactivates the display of the weight with large digits.
308	Change language	from 0 to 4 or 255 (custom)	Allows you to change the program language in real time. Useful for self service systems.
309	Brightness adjustment	from 1 to 5	Allows you to adjust brightness of the display's back lighting.
310	Cross light (3 colors) function	-	Activates/deactivates the colour change function of the display depending on the set tolerances. This function also acts on the built-in LED traffic light (if present).
311	Wait synchronism (for Sequence)	For use by the manufacturer.	For use by the manufacturer.

Diagnostic		Preamble	Description
401	Indicator information	-	Displays all the metrological/legal information of the indicator and of the installed program.
402	Weight test	-	Displays the current weight of the scale, even in error conditions (underload, overload, etc.).
403	Display test	-	Display of basic colours in sequence (White / Black and RGB)
404	Keyboard test	-	Allows you to verify correct operation of the touch screen and of the built-in keyboard (if present).
405	Voltage levels	-	Displays the voltage value at the input of the power supply and battery (if present).
406	Serial ports test	-	For use by the manufacturer.
407	CTS test	-	Test of the status of the control signal from the printer.
408	Printout test	-	Allows you to send the printer the selected printing format (from "1" to "30" or else "0" to send all formats).
409	Outputs and inputs test	-	Allows you to verify the status of the digital inputs and testing of the relay outputs/ built-in traffic light. By clicking the desired output you activate/deactivate the connected device. Click "R", "Y" or "G" to test the built-in traffic light (if present).
410	Analog output test	-	Allows you to test the analogue output: enter a digital value for real time updating of the analogue output.
413	Events log viewer	-	Views the list of the last ten events of the selected category.
450	Metric information	-	Displays all the metrological information of the connected scales (Max, Min, and).
451	Serial Com test (runtime)	-	<p>When you have chosen the communication port to be verified, the tool displays the characters received and transmitted in real time, in ASCII or binary format.</p>  <p>The screenshot shows a software interface for a serial communication test. At the top, a display shows 'BRUTTO' and a large '0' with 'kg' below it. Below this are two large text areas labeled 'RX:' and 'TX:'. To the right of these areas, blue arrows point to them with labels 'Data received' and 'Data transmitted'. Below the RX/TX areas is a control panel with several buttons: 'ESC', 'BINARY', 'PAUSE', and 'CLEAR' in a top row; '0+', a central input field, and 'T-' in a middle row; and 'ERSTW.', 'ZWEITW.', 'ENDE', and '>>' in a bottom row. Blue arrows point from text labels to specific buttons: 'Exits the function' points to 'ESC'; 'Switches the ASCII / Binary display' points to 'BINARY'; 'Stops transponder of characters.' points to 'PAUSE'; and 'Deletes the data transmitted/received' points to 'CLEAR'.</p>
452	Peripheral untis test (runtime)	-	Displays the current status of all the inputs, relay outputs, analogue output and serial ports.
453	Main screen guide	-	Summarised guide of all the features and main icons on the work screen.

Input texts		Preamble	Description
502	Input texts resetting	99	Allows you to delete the content of all the input texts.
		from 0 to 49	Allows you to delete the content of the specified input text.
518	Text visualization time	0	Permanent display of the input text, specified in function "519", in the messages area (status bar) of the work screen.
		from 1 to 100 sec	Time the input text is displayed in the status bar.
		101	Display of the input text until the weight is > 0 kg.
		102	Display of the input text until the weight is stable.
		103	Display of the input text until output 1 is OFF.
		104	Display of the input text until output 2 is OFF.
		105	Display of the input text until output 3 is OFF.
519	Show text on status bar	from 0 to 14	Views the input text specified in the preamble in the message area (status bar) for the time set in function "518"

Databases		Preamble	Description
601	Customers database	-	Access compilation of customer database.
602	Customer selection	-1	Access the complete customer database.
		from 1 to 499	Access the customer database to select the desired record.
		9999	Unselect the active record.
603	Material database	-	Access compilation of materials database.
604	Material selection	-1	Access the complete materials database.
		from 1 to 499	Access the materials database to select the desired record.
		9999	Unselect the active record.
		10000	Selection with alphanumerical filter.
		10001	Selection by numerical index.
		10002	Activates the selection by image. Image format 68x68 px. Image stored on SD.
		10003	Activates the selection by image. Image format 138x33 px. Image stored on SD.
		10004	Activates the selection by image. Image format 68x33 px. Image stored on SD.
		10005	Activates the selection by image. Image format 68x68 px. Image stored on USB.
		10006	Activates the selection by image. Image format 138x33 px. Image stored on USB.
		10007	Activates the selection by image. Image format 68x33 px. Image stored on USB.
605	Vehicle database	-	Access compilation of vehicles database.
606	Vehicle selection	-1	Access the complete vehicles database.
		from 1 to 499	Access the vehicles database to select the desired record.
		9999	Unselect the active record.
607	Progressives database	-	Not used in the vehicles weighing application.
608	Cards database	-	Access compilation of cards database.
609	Text database	-	Access compilation of input texts
610	Text selection	-	Selection of input texts.
611	Supplier database	-	Access compilation of suppliers database.
612	Supplier selection	-1	Access the complete suppliers database.
		from 1 to 249	Access the suppliers database to select the desired record.
613	Card selection	-1	Access the complete cards database.
		from 1 to 999	Access the cards database to select the desired record.
		9999	Unselect the active record.

AF09 functions		Preamble	Description
701	First weigh	-	Acquisition of the first weigh.
702	Second weigh	-	Acquisition of the second weigh.
703	Minimum threshold	-	Setting of minimum acquisition threshold.
704	Maximum threshold	-	Setting of maximum acquisition threshold.
705	Reset weighs list	-	Allows you to delete all the first weighs open.
708	Weighs list	-	Displays the list of the last 1000 open/closed weighs.
709	Preset weight for first weigh	-	Quick entry of the known weight to use as the first weigh.
720	Close weighing cycle	-	Manual closing of weighing cycle.
721	Reset weighing cycle	-	Allows you to delete the weighing cycle without storing the weights recorded.
722	Reset weighing cycle error	-	Allows you to continue the weighing operation instead of interrupting it after an axle acquisition error.
723	Weighing cycle pause	-	Press to pause the weighing cycle. Press again to restart the cycle.
724	Set manual weighing	-	Allows you to change the weighing mode. The weighing filter and parameters are edited.
725	Set static weighing	-	Allows you to change the weighing mode. The weighing filter and parameters are edited.
726	Set dynamic weighing	-	Allows you to change the weighing mode. The weighing filter and parameters are edited.
727	Minimum axle weight	-	Minimum weight value for each axle of the vehicle required to enable acquisition.
728	Average weight samples	-	Number of weighing readings when weighing each single axle.
729	Cycles time interval (sec)	-	Number of seconds elapsed (with less weight of "Minimum axle weight") with which the weighing cycle ends automatically.
730	Beginning axles to skip	-	Allows you to set the number of axles not to accumulate at the beginning of weighing.
731	Ending axles to skip	-	Allows you to set the number of axles not to accumulate at the end of the weighing cycle.
732	Error enable	-	For use by the manufacturer.
733	Error disable	-	For use by the manufacturer.
734	Speed limit	-	Maximum speed with which the vehicle can drive on the platform.
735	Platform width	-	Allows you to calculate the correct speed of the vehicle (expressed in cm).
738	Enable min. speed checking	-	Enable the minimum speed control of the vehicle.
739	Disable min. speed checking	-	Disable the minimum speed control of the vehicle.

Totals		Preamble	Description																								
801	View all totals	-	<div><div>Alle Summen anzeigen.</div><table><thead><tr><th>Summen-Art</th><th>NETTO</th><th>WÄGUNGEN</th></tr></thead><tbody><tr><td>ZWISCHEN</td><td>0 kg</td><td>0</td></tr><tr><td>GESAMT</td><td>0 kg</td><td>0</td></tr><tr><td>TAGES</td><td>0 kg</td><td>0</td></tr><tr><td>KUNDE</td><td>0 kg</td><td>0</td></tr><tr><td>MATERIAL</td><td>0 kg</td><td>0</td></tr><tr><td>FAHRZEUG</td><td>0 kg</td><td>0</td></tr><tr><td>LIEFERANT</td><td>0 kg</td><td>0</td></tr></tbody></table><div>Esc</div></div>	Summen-Art	NETTO	WÄGUNGEN	ZWISCHEN	0 kg	0	GESAMT	0 kg	0	TAGES	0 kg	0	KUNDE	0 kg	0	MATERIAL	0 kg	0	FAHRZEUG	0 kg	0	LIEFERANT	0 kg	0
Summen-Art	NETTO	WÄGUNGEN																									
ZWISCHEN	0 kg	0																									
GESAMT	0 kg	0																									
TAGES	0 kg	0																									
KUNDE	0 kg	0																									
MATERIAL	0 kg	0																									
FAHRZEUG	0 kg	0																									
LIEFERANT	0 kg	0																									
802	Reset all totals	-	Allows you to reset all the accumulated totals in one step.																								
803	Weighs to auto print partial t.	-	Not used in the vehicles weighing application.																								
804	Print partial total	-	Allows you to print the partial total accumulated.																								
805	Reset partial total	-	Allows you to reset the partial total accumulated.																								
806	Print general total	-	Allows you to print the general total accumulated.																								
807	Reset general total	-	Allows you to reset the general total accumulated.																								
808	Print grand total	-	Allows you to print the grand total accumulated.																								
809	Reset grand total	-	Allows you to reset the grand total accumulated.																								
850	Print customer total	-	Allows you to print the total of the selected customer.																								
851	Reset customer total	-	Allows you to reset the total of the selected customer.																								
852	Print customer total	-	Allows you to print the total of all customers in one step.																								
853	Reset customers total	-	Allows you to reset the total of all customers in one step.																								
854	Print material total	-	Allows you to print the total of the selected material.																								
855	Reset material total	-	Allows you to reset the total of the selected material.																								
856	Print materials total	-	Allows you to print the total of all materials in one step.																								
857	Reset materials total	-	Allows you to reset the total of all materials in one step.																								
858	Print vehicle total	-	Allows you to print the total of the selected vehicle.																								
859	Reset vehicle total	-	Allows you to reset the total of the selected vehicle.																								
860	Print vehicles total	-	Allows you to print the total of all vehicles in one step.																								
861	Reset vehicles total	-	Allows you to reset the total of all vehicles in one step.																								
862	Print supplier total	-	Allows you to print the total of the selected supplier.																								
863	Reset supplier total	-	Allows you to reset the total of the selected supplier.																								
864	Print suppliers total	-	Allows you to print the total of all suppliers in one step.																								
865	Reset suppliers total	-	Allows you to reset the total of all suppliers in one step.																								

Progressives		Preamble	Description
901	Additional value	For use by the manufacturer.	For use by the manufacturer.
902	Progressives digits	For use by the manufacturer.	For use by the manufacturer.
903	Ticket progressive	For use by the manufacturer.	For use by the manufacturer.
904	Lot progressive	For use by the manufacturer.	For use by the manufacturer.

Network functions		Preamble	Description
1001	Network state	-	For use by the manufacturer.
1002	Network monitor	-	Indicates the online tools and indicates who the "Master" indicator is.
1003	Network archive alignment	-	Aligns the databases of all the online indicators in real time.
1004	Unlock weighing list records	-	For use by the manufacturer.
1005	Connect network	-	Allows you to connect the indicator to the network.
1006	Disconnect network	-	Allows you to disconnect the indicator from the network.

Notes

[illegible]

[illegible]

[illegible]

This publication, or portions thereof, may not be duplicated without written permission from the Manufacturer. All information herein is based on the data available at the time of publication. The Manufacturer reserves the right to make changes to its products at any time without notice and without incurring any penalty. We therefore recommend that you always check for any updates.

The individual in charge of operating the scale must ensure that all safety regulations in force in the country of use are applied, ensuring that the appliance is used in accordance with the purpose it is intended for and to avoid any danger for the user.

The Manufacturer declines any liability arising from any weighing operation errors.

**HEAD OFFICE**

Via Della Fisica, 20
41042 Spezzano di Fiorano, Modena - Italy
Tel. +39 0536 843418 - Fax +39 0536 843521

SERVICE ASSISTANCE

Via Dell'Elettronica, 15
41042 Spezzano di Fiorano, Modena - Italy
Tel. +39 0536 921784 - Fax +39 0536 926654

www.diniargeo.com

Stamp of authorised support centre

